

NOTE: this procedure is required to *pre-treat* corner areas before making the main application of LATICRETE[®] 9235 Waterproofing Membrane - read LATICRETE Data Sheet s WPAF.5 and 236.0 for full installation instructions/details, including substrate and preparation requirements.

Inside and Outside Corners

- Cut a 6" (150mm) long piece from the 6" (150mm) wide LATICRETE 9235 Waterproofing Membrane Reinforcing Fabric roll, making a 6"x6" (150mm x 150mm) square;
- Make a cut from the center of one edge halfway to the center of the square, as per the drawing below;



- Cover corner surfaces with a liberal coat of LATICRETE 9235 Waterproofing Membrane Liquid, approximately 8" (200mm) wide [i.e. apply approximately 4" (100mm) of LATICRETE 9235 Waterproofing Membrane Liquid over the wall and floor surfaces bordering the corner];
- Place the *uncut* half of the square into the LATICRETE 9235 Waterproofing Membrane Liquid spread on the *wall*;
- Press the square firmly into the *wall* with a brush, allowing the LATICRETE 9235 Waterproofing Membrane Liquid to completely bleed through and saturate the LATICRETE 9235 Waterproofing Membrane Reinforcing Fabric;
- Then place Tab A of the same square into the LATICRETE 9235 Waterproofing Membrane Liquid spread on the *floor*;
- Press Tab A firmly into the *floor* with a brush, allowing the LATICRETE 9235 Waterproofing Membrane Liquid to completely bleed through and saturate the LATICRETE 9235 Waterproofing Membrane Reinforcing Fabric;
- Apply additional LATICRETE 9235 Waterproofing Membrane Liquid over Tab A and fold Tab B over Tab A;
- Press Tab B firmly with a brush, allowing the LATICRETE 9235 Waterproofing Membrane Liquid to completely bleed through and saturate the LATICRETE 9235 Waterproofing Membrane Reinforcing Fabric;
- Then apply another liberal coat of LATICRETE 9235 Waterproofing Membrane Liquid over the entire surface of the square just installed;
- Inspect the surface for pinholes and apply additional LATICRETE 9235 Waterproofing Membrane Liquid as needed;
- Once the last coat of LATICRETE 9235 Waterproofing Membrane Liquid has dried to the touch, proceed with the main application of LATICRETE 9235 Waterproofing Membrane - making sure that the LATICRETE 9235 Waterproofing Membrane is flashed 3" (75mm) up the walls at all cove areas.

Technical Data Sheets are subject to change without notice. For latest revision, check our website @ www.laticrete.com
TDS188.doc R 3 January 2005

LATICRETE, LATAPOXY and the  logo are Registered Trademarks of LATICRETE International, Inc.

