



**LATICRETE® 9235 WATERPROOFING  
MEMBRANE CHECKLIST  
TDS 189**

**Note:** the following items should be reviewed after the installation of LATICRETE 9235 Waterproofing Membrane and before installation of ceramic or stone tile:

1. all joints, coves, corners and changes of plane are taped;
2. reinforcing fabric is totally encapsulated by the liquid – no visible white fabric;
3. all fabric seams are overlapped by 2" (50 mm);
4. no scuff marks, rips or other damages to the membrane;
5. sealant at drains, pipe penetrations, expansion joints per the details;
6. reinforcing fabric is flashed up verticals 4" (100 mm);
7. no bubbles.

**Corrections:**

1. un-taped joints require an application of 6" (150 mm) wide fabric over the membrane per D.S. 236.5;
2. fabric that has not been totally encapsulated requires a full membrane application over the first;
3. seams that have not been properly overlapped require an application of 6" (150 mm) wide fabric over the membrane per D.S. 236.5;
4. damaged membrane requires patching with fabric, approximately 6" (150 mm) wider and longer than the damaged area, applied per D.S. 236.5;
5. sealant must be properly installed;
6. verticals that are not flashed require an application of 6" (150 mm) fabric per D.S. 236.5;
7. bubbles must be cut out and the substrate examined to determine the cause; once the substrate condition has been corrected, the area requires patching with fabric, approximately 6" (150 mm) wider and longer than the bubble, applied per D.S. 236.5;

Technical Data Sheets are subject to change without notice. For latest revision, check our website @ [www.laticrete.com](http://www.laticrete.com) TDS 189.doc R 3 January 2005

**LATICRETE, LATAPOXY and the  logo are Registered Trademarks of LATICRETE International, Inc.**

